


CFS Padding Clamp

Instructions



Small
Spine Length up to 5"





Normal
Spine Length 5" to 8.5"



Wide
Spine Length 8.5" to 12"

Using a wider setting than what is recommended may cause damage to clamp


Proper Bolt Threading



Clamping Notepads




- 1 For thin stacks of notepads, lie clamp flat on it's side.(fig. A)
- 2 Insert binding edge of jogged pad into clamp, ensuring the edge is making full, flat contact with work surface.
- 3 Tighten wingnuts enough to hold paper firmly in place.
- 4 Flip Padding Clamp upright.(Fig. B)



- 5 Apply a thin layer of padding compound with a brush, starting from the center and brushing towards the edges.(Fig. C)



- 6 Allow time to dry before adding more coats or releasing the Padding Clamp.



- For large stacks, place the clamp up against a flat surface.
- Add a 1" stack of paper or cardstock under the overhanging notepad stack.
- Place notepad stack inside clamp, flush with the flat surface.
- Tighten Clamp, turn clamped stack to expose edge to be glued.

